



BT01 Battery Tester (For AAA, AA, C & D Type Batteries)

TECHNICAL SPECIFICATIONS

GENERAL

- Suitable for testing AAA, AA, C & D type batteries (rechargeable or non-rechargeable).
- Can also test standard 9 volt (1604, 522, 6LR61) batteries.
- Easy to use.
- Just place battery between base contact point and the extending arm contact point.
- Ensure the +ve (button) end of the battery touches the extending arm contact point and the -ve (flat base) end of the battery touches the lower contact point of the battery tester.
- See photo for typical use.
- Needle moves to show battery condition.
- Perfect for solar light battery testing and troubleshooting.
- Batteries not included.



*SUBJECT TO OUR TERMS & CONDITIONS, AND RETURNS POLICY

One Year*
Warranty ✓

Low Price
Guarantee ✓

No Quibble*
Returns ✓

UK & Ireland
Shipping ✓

Lifetime
Tech Support ✓

Communications House, 26 York Street, • London, W1U 6PZ • Great Britain • Phone: 020 7873 2262 • Fax: 020 7806 8372

MONDAY - FRIDAY 9:00AM - 9:00PM (UK TIME)

www.solarilluminations.co.uk • sales@solarilluminations.co.uk